



EasyClean

CENTRAL VACUUM
INSTRUCTION MANUAL

SAFETY INSTRUCTIONS

READ THIS INSTRUCTIONS BEFORE USING THIS CENTRAL VACUUM SYSTEM

- This vacuum cleaner is intended for dry pick up only. Do not use on wet surfaces or pick up any liquids, hot debris or any flammable items that would cause harm to the vacuum cleaner.
- Do not allow vacuum to be used as a toy. Close supervision is necessary when this vacuum is used by or near children.
- Use this vacuum only for its intended use as described in this manual.
- Use only with recommended accessories. The use of attachments not recommended by manufacturer may cause fire, electric shock, injury or damage to system components.
- Never operate this vacuum if it has a damaged hose or plug, if it is not working properly, or if it has been dropped or damaged. Return to authorized dealer/distributor for repair.
- Do not put any object into openings. Do not use with any opening blocked.
- Keep free of dust, lint, hair and anything that may reduce air flow/suction. Lack of air flow will cause the motor to overheat.
- This vacuum cleaner creates suction. Keep hair, face, fingers, all body parts and loose clothing away from any openings.
- Never operate without dust bag and/or filter in place.
- Do not locate the power unit in a high temperature area or where it is inaccessible, for example, an attic or crawl space.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- Do not use on wet surfaces.
- Do not vacuum drywall dust or baking flour as it may cause damage to your vacuum.
- This appliance is not intended for use by persons, (including children), with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.

YOUR NEW EASY CLEAN CENTRAL VACUUM UNIT

Easy Clean Customer:

You have purchased a new Easy Clean Central Vacuum Unit! This Easy Clean model is an innovative and intuitive Central Vacuum Unit. Thank you for your support. For maximum benefit, please read this instruction manual before installing and operating your central vacuum. You will want to keep these instructions for future reference.

Model _____

Serial Number _____

Purchase Date _____

The sticker with the the central vacuum unit information will look like this example:



EasyClean

EC 300

1600 W

230 V

7A

50 - 60 Hz

N° B 19954

Aspiri Casa - Aspiração Centralizada, Lda.

R. A. Casal do Monte

Rua da das Rosas, Anexo 12

3840-121 Alentejo do Porto Fino

Portugal

www.aspiriCasa.pt

geral@aspiriCasa.pt

+351 21 325 33 54 / 5



Opening the Package



Your Central Vacuum and its accompanying hardware and accessories are carefully packed in a cardboard package designed to protect it from transportation damage. You will find the pieces needed to hook up your central vacuum packaged in the deposit.

INSTALLATION OF THE POWER UNIT

HOW TO INSTALL

The power unit hangs on the mounting bracket which is screwed to the wall. For proper motor cooling, there must be a good distance between unit and the ceiling. If mounting on plaster or panel walls, be sure mounting screws enter studs. If mounting on concrete wall, drill the wall with a masonry bit and insert the appropriate wall anchors. Strip the low-voltage wires that were installed with the main trunk line.


Do not glue the connection to the power unit in case you wish to remove at a future date. This unit may be vented outside. Do not exceed a run of over 6 meters off of exhaust, Do not vent power unit into a wall, ceiling or concealed space of a building.




AIR INTAKE

Your power unit has been designed for either a left or right pipe intake. This is to give you more flexibility when choosing the location you wish to hang your power unit. To change the direction of the intake simply remove the cap from the air intake on the side where you want to install and place it on the air intake of the other side. Make sure that one of the air entry are covered.


INSTALLATION OF THE POWER UNIT




1. Mark the place to drill the holes




2. Install the mounting bracket and screw it




3. Hang the central in the mounting bracket



4. Insert the tube from the installation into the air intake of the central unit




5. Connect the 24V cable to the appropriate connector



6. Plug the power cord into an AC outlet (220 V)

EASYCLEAN SAFETY VALVE


Easy Clean offers with the central vacuum units a safety valve. This valve will protect the motor of some situations that can damage it, for example an obstruction in the pipe system or a saturated filter. Use this safety valve to extend the lifetime of your central vacuum unit, follow these instructions to a correct installation.




MAINTENANCE

CLEANING THE DUST CONTAINER


All of the dirt vacuumed from your home is captured in the dirt bucket located on the bottom of your power unit. It is important that you remember to empty it on a regular basis to ensure optimal performance. The frequency required is dependent on many factors in your home (i.e. type of floor coverings, number of people living in the home and how many pets). A general rule is to empty the dirt receptacle twice a year in spring and in fall. It is ideal to empty the dirt bucket when it is half full.




1. Detach the dust container.




2. Remove the airtight ring.



3. Empty the dust container.



4. Replace the airtight ring.



5. Set the dust container back in place.


MAINTENANCE

REPLACE/ CLEANING THE FILTER


It is recommended that you clean your filter each 2 months. For the polyester filter you can use water to clean it, but be careful when you put the filter again in the machine, be sure that there is no water on it.

For the paper filter please don't use water because you will damage it.


See the instructions on the following pictures.




1. Detach the dust container.




2. Unscrew the handle and remove the dirty filter.




3. Replace the filter and screw the handle.




4. Set the dust container back in place.



5. Mount the accessory with reduced opening.



6. Clean the dirty parts of the filter.



7. Attest that there is no cracks.

TROUBLE-SHOOTING

The Central vacuum system is not operating:

- a) Make sure the power unit is connected to the power supply;
- b) Check your home's electrical frame;
- c) Check the central vacuum system connection and the electrical installation voltage;
- d) Check the entrance inlet to make certain that the terminals are working properly;
- e) Make sure the power supply arrives to the plug where the power unit is connected;
- f) Press the protection cut-out switch.

The Central vacuum system does not stop operating:

- a) Check for any short circuit in the control terminals;
- b) Check to make certain that the hose is inserted into an inlet;
- c) Make sure that there aren't any objects in contact with one inlet.

IF AT THE END OF ALL THESE SOLUTIONS YOUR CENTRAL VACUUM SYSTEM STILL PRESENT PROBLEMS, DO NOT HESITATE IN CONTACT US, YOUR TECHNICIANS ARE ALWAYS READY TO HELP YOU IN YOUR PROBLEMS SOLUTION.



EasyClean